ProVa-Shower System

All the cowater tight No waiting installed in the penetration of the penetration

For Tiled Showers

- All the components required to build a fully bonded water tight assembly for tiled showers.
- No waiting time between steps; tiles can be installed immediately.
- Protects wall cavities against water and vapor penetration.
- Prefabricated sloped pan eliminates mortar bed, reducing weight and installation time.

48" x 48" Center Drain



All Shower
Systems Include:

- A. ProVa-Mat
- B. ProVa-Joint strip
- C. ProVa-Drain grate
- D. ProVa-Drain
- E. ProVa-Mat floor panel
- F. ProVa-Pan
- G. ProVa-Corners

OVCREEN FLOORING GROUP

A complete, easy to install WATERPROOFING SYSTEM for maintenance-free tiled showers

Off Center Drain


32"x 60"



Drain _____ Grate Color: ____ ProVa-Shower Curb and ProVa-Shower Extension kit __

Available in PVC and ABS





- Black
- Bronze
- Stainless Steel
- Brass
- Chrome(Standard)





Shower Curb System 2 Extension Kits Creates a 72" x 72"

See Our Installation Video at www.loxcreenflooring.com/installation