

*Introducing*

# ProVa-Flor

**Subfloor System**

**Makes floors over concrete...**  
*Comfortable • Healthy • Warm • Dry*



It's like having  
an **"Above Grade"** floor!

**FOR DRY FLOORS**

**OVER**

**DAMP CONCRETE!**

**INSTALLATION PROCEDURES:**

ProVa-Flor is installed in strips, dimples down, over the concrete slab. The smooth tab (selvage edge) on the roll overlaps and is sealed to the adjacent strip. An OSB load spreading sheet is then placed over the ProVa-Flor and fastened to the concrete in 24" intervals.

All types of flooring may then be installed, following the manufacturers instructions for "above grade" floors. Detailed instructions are included in each roll.

